



Advanced Technology for Beds

Mod. Tbed Desk


Assembly instructions




assembly instructions




A
M8x60




B
4x50




C
M8x45




D
M8x20




E
4x20




F
M6x12




G
M8




Hx4
Nylon




Ix2
M8




Jx2
M8




Kx2




Lx2




Mx1




Nx1




Ox1




Px1




Qx1




Rx2



Sx2





Tx2




Ux1




Vx2




4-5mm



13mm









STEP 01




If some screws are too close to the edge of the panels, reduce the quantities from 4 to 2 a plate




STEP 02




Hex 4mm



Hex 4mm





Hex 4mm




O	P	Q
x1	x1	x1
R	S	F
x2	x2	x12
		M6X12


STEP 03




F
x4

M6X12

STEP 04



E
x8

4X20


STEP 05



U	J
x1	x2
L.870 x4	B
L.920 x4	x4
L.1020 x4	
L.1220 x4	
L.1420 x4	
L.1620 x4	
L.1820 x4	4x50


M
x1

N	F	R
x1	x12	x2
	M6X12	









STEP 06



4mm




4mm





F	x4
	
M6X12	
H	x4
	
I	x2
	


T	x2
	
V	x2
	







STEP 07






G	A
x2	x2
	
	M8X60

STEP 08

D
x2

M8X20



G	C
x2	x2
	
	M8X45



MAINTENANCE - CLEANING - LUBRIFICATION - DISPOSAL

MAINTENANCE

Make periodical check of all screwed on parts, including also the steadiness of the wall fixation, by checking that no elements are lose, folded, damaged or missing.

Also check that the elements of the bedspring, the handling mechanism, the gas springs, the attachment to the container and the wall are not loose, bent, damaged, or missing. Maintenance must be performed every 60 opening / closing cycles and / or at least once a year.

CLEANING AND LUBRIFICATION

The cleaning of all metal parts shall be made with a humid sponge or cloth.

Don't use any solvents or abrasive materials.

Lubrication of mobile elements as rotation pivots and door hinges, shall be made every 60 cycles with a lubricant.

DISPOSAL

The different parts shall be disposed in special containers in accordance with the ruling standards.
DO NOT DUMP.

